

⚠ CAUTION

Before Installation

- Use **ONLY** on vehicles with roof racks.
- Clean the vehicle roof and the pack bottom to avoid scratching.
- Do not exceed the manufacturer's roof rack weight limit.

Loading And Unloading

- When loading distribute the weight evenly and put heavier items on the bottom.

- Never toss items into your Roof Cargo Pack—you could damage your roof.
- Product will not prevent dents resulting from improper loading, securing or driving.
- Never try to remove a loaded Roof Cargo Pack from your vehicle's roof.
- For security use a small padlock on the zipper.

Driving In Wet Conditions

Your Roof Cargo Pack PVC material is waterproof, but no pack is completely waterproof. **Pack items that can be damaged by water in plastic.**



Installation

1. To avoid scratching be sure the roof area and pack bottom are free of dirt and grit.

Center your Roof Cargo Pack on the roof of your vehicle within the luggage rack. Put the cover on the roof with the straps on the top and the end without a zipper toward the front.

2. Load your Roof Cargo Pack. First wrap any items that can be damaged by water in plastic.


Put the heaviest items on the bottom and use soft items like clothes or pillows to fill spaces. Place things you will need first toward the outside by the zippers. Now zip your Roof Cargo Pack shut and fold the protective flap down over the zipper.

3. Your Roof Cargo Pack can be attached to a variety of roof racks.

The straps can be attached by either of two methods:


Attach To The Rack Beams

Loop the straps around the front, back and side beams as shown. Then latch the buckles and adjust the strap length. Tuck the clips under if not needed.



Attach To The Rack Rings

The straps also have snap clips that can be attached to rack rings. Snap the clips into the rings and tighten the straps.



Prepare For Driving

Before driving check that all the straps are tight and zippers are closed. After adjusting the straps, secure or tie off any extra strap lengths—do not leave loose.

If you hear a flapping noise pull over immediately and check the straps.

Care

To avoid mildew or fading, store your Roof Cargo Pack only when completely dry and out of the direct sun.

Cleaning

Your Roof Cargo Pack may be cleaned with a soft rag and some warm water.

Warranty

This product is factory warranted for workmanship and materials for three years after purchase.

This warranty does not cover items carried in the Roof Cargo Pack.

Distributed by Target Corporation
Minneapolis, MN 55403
© 2005 Target Brands, Inc.
All Rights Reserved
www.target.com